



OXY-03

OXY - 03 OZONE COMPLETE

- 1) Rest the bottom base of the OXY-03 on the top base of tank.
- 2) Attach clamps onto piping. Check bolts & screws for tightness. Do not overtighten.

Note: Due to condensation the OXY-03 must be in a vertical position with fan at bottom.

- 3) Remove current injection check valve shown on page 2 and replace with part 70000X250 provided. Insert blue tubing from OXY-03 to air intake hose barb on the 70000X250.

Note: The 70000X250 must be installed when using ozone!

- 4) Insert relay cord from OXY-03 into "B" port near power supply of control valve.
- 5) Plug in power cord to a 120v uninterrupted wall socket.

Note: The OXY-03 will only activate during the air replenish cycle.





