




OXY-03



Once installation is complete, the OXY-03 will automatically activate during every air replenish cycle. No additional valve programming is necessary